

Client:	VotingWorks	Doc. No.: VWX-001-D022
Project:	Ballot Receptacle	Revision: X01
Doc. Title:	Door Latch Assembly Instruction	Date: 2024-10-16

1.0 PURPOSE

The purpose of this document is to describe the required parts, assemblies, tools, preparation, and process to assemble the Door Latch Assembly (VX~01-10084).

2.0 PARTS & ASSEMBLIES

2.1 Made-To-Spec (MTS)

Item Number	Description	Reference Name
VX~02-10088	TUBE, DOOR LATCH	TUBE
VX~02-10092	BEARING, DOOR LATCH, MACHINED	BEARING BLOCK
VX~02-10093	MOUNT, DOOR LATCH, MACHINED	MOUNTING BLOCK
VX~02-10097	HANDLE, DOOR	HANDLE
VX~02-10098	LATCH, DOOR	LATCH HOOK
VX~02-10104	SPRING, RETURN, DOOR LATCH	RETURN SPRING

2.2 Off-The-Shelf (OTS)

Item Number	Description	Reference Name
VX~99-10105	POP RIVET, 1/8 IN x 0.65 IN, AL	RIVET



Client:	VotingWorks	Doc. No.: VWX-001-D022
Project:	Ballot Receptacle	Revision: X01
Doc. Title:	Door Latch Assembly Instruction	Date: 2024-10-16

3.0 TOOLS

3.1 Made-To-Spec (MTS)

Item Number	Description

3.2 Off-The-Shelf (OTS)

Supplier	Part Number	Description
ZIPP	ZT1017VS	PNUEMATIC BLIND RIVET TOOL

4.0 PREPARATION

The blind rivet tool requires a 1/8" tip.

5.0 ASSEMBLY PROCESS

Assemble the Door Latch Assembly (VX~01-10084) as defined in the following steps.



Client:	VotingWorks	Doc. No.: VWX-001-D022
Project:	Ballot Receptacle	Revision: X01
Doc. Title:	Door Latch Assembly Instruction	Date: 2024-10-16

STEP 1 INSTALL BEARINGS


1.1 Slide BEARING BLOCK over the bottom of TUBE with the flange facing toward the center of TUBE.





Client:	VotingWorks	Doc. No.: VWX-001-D022
Project:	Ballot Receptacle	Revision: X01
Doc. Title:	Door Latch Assembly Instruction	Date: 2024-10-16

- 1.2 Slide RETURN SPRING over the top of TUBE and align with the second slot from the top in the orientation shown.
- 1.3 Slide MOUNTING BLOCK over the top of TUBE and align with the first slot from the top in the orientation shown.






Client:	VotingWorks	Doc. No.: VWX-001-D022
Project:	Ballot Receptacle	Revision: X01
Doc. Title:	Door Latch Assembly Instruction	Date: 2024-10-16

INSTALL HANDLE STEP 2

- 2.1 Align HANDLE with top slot in TUBE
- 2.2 Place RIVETS through HANDLE and TUBE




Page

5 of 13



Client:	VotingWorks	Doc. No.: VWX-001-D022
Project:	Ballot Receptacle	Revision: X01
Doc. Title:	Door Latch Assembly Instruction	Date: 2024-10-16

2.3 Cinch RIVETS in place with RIVET GUN






Client:	VotingWorks	Doc. No.: VWX-001-D022
Project:	Ballot Receptacle	Revision: X01
Doc. Title:	Door Latch Assembly Instruction	Date: 2024-10-16

STEP 3 INSTALL LATCH HOOKS


3.1 Spread RETURN SPRING open





Client:	VotingWorks	Doc. No.: VWX-001-D022
Project:	Ballot Receptacle	Revision: X01
Doc. Title	: Door Latch Assembly Instruction	Date: 2024-10-16


3.2 Slip LATCH HOOK through TORSION SPRING arm and align with slot in TUBE





Client: VotingWorks		Doc. No.: VWX-001-D022	
Project:	Ballot Receptacle	Revision: X01	
Doc. Title: Door Latch Assembly Instruction		Date: 2024-10-16	

3.3 Place RIVETS through LATCH HOOK and TUBE



CONFIDENTIAL



Client: VotingWorks		Doc. No.: VWX-001-D022	
Project:	Ballot Receptacle	Revision: X01	
Doc. Title: Door Latch Assembly Instruction		Date: 2024-10-16	


3.4 Cinch RIVETS in place with RIVET GUN





Client: VotingWorks		Doc. No.: VWX-001-D022	
Project:	Ballot Receptacle	Revision: X01	
Doc. Title:	Door Latch Assembly Instruction	Date: 2024-10-16	

- 3.5 Align LATCH HOOK with bottom slot in TUBE. Bottom LATCH HOOK should be in the same orientation as top LATCH HOOK.
- 3.6 Place RIVETS through LATCH HOOK and TUBE




Page

11 of 13



Client: VotingWorks		Doc. No.: VWX-001-D022	
Project:	Ballot Receptacle	Revision: X01	
Doc. Title: Door Latch Assembly Instruction		Date: 2024-10-16	

3.7 Cinch RIVETS in place with RIVET GUN



Page

12 of 13



Client: VotingWorks		Doc. No.: VWX-001-D022	
Project:	Ballot Receptacle	Revision: X01	
Doc. Title: Door Latch Assembly Instruction		Date: 2024-10-16	

REVISION HISTORY AND APPROVALS

If this document is a released alpha-revision, a record of the approvers and specifics of the approval process associated with each released version of this document is contained in the CR# listed in the table, and available for review on NOVO's online CR system.

Rev	Description	CR#	Date	Submitted By
X01	Initial Draft	N/A		